


KIT & GSPRO Auto-Putt Setting

This document is designed to help with setting the Auto-Putt for a KIT on the GSPRO application before starting a round of golf. KIT does not track putting, change this setting per every round of golf if not already preset.

1. Within the **GSPRO Application**, when starting a round of golf, open the **Match Settings**.
2. Change the **Match Settings** to the following:
 - **Gimmie/Auto Putt – AutoPutt Fixed**



3. Place the **KIT 8 -10"** from the hitting mat.

4. **Begin Playing!**

NOTE: Wi-Fi to the laptop is crucial for these two technologies to connect; ensure you have good signal when operating the **Full Swing KIT Studio**.