


FULL SWING KIT




QUICK START GUIDE

Version 2


CONTENTS




Carrying Case



Launch Monitor



Charging Cable



Charger

COMPATIBILITY

- iPhone® (10 and higher), running iOS 14 and higher
- iPad® (7th generation and higher), running iOS 14 and higher
- iPad® Air (3rd generation and higher), running iOS 14 and higher
- iPad® Pro (all models), running iOS 14 and higher
- Apple Watch® (3 or higher), running watchOS 7 or higher
- Apple AirPods® or most any Bluetooth® headphones

SAFETY & USER GUIDES

For detailed safety information and the full user guide, please scan the QR code below with your camera:




1. CHARGE IT UP

- Remove the charger and cable from the inside pocket of the carrying case
- Gently open the rubber charging port cover on the left side of your Full Swing KIT, attach the charging cable, then attach the charger to the wall
- Allow approximately 5 hours for a full charge

NOTE: You can pair and configure your KIT while in charging mode.
Please continue in this mode for steps 2 through 4.

USB CHARGING PORT



2. DOWNLOAD THE APP

To download and install the Full Swing app:

- Scan the QR Code below with your camera:



- Alternatively, search for **Full Swing** in the Apple App Store®

3. PAIR & CONFIGURE

Open the Full Swing app and follow the onscreen instructions to:

- Create a Full Swing account or log in with an existing account
- Pair your KIT with your mobile device
NOTE: Tap the **Power** button to view your **Device Name** in the upper left corner of the display
- Join your KIT to a Wi-Fi network (required for updates)

4. CHECK FOR UPDATES


Your KIT will automatically download and install new updates while it is charging and connected to Wi-Fi. For the best experience, please allow any updates to finish before using your KIT.

NOTE: Do not power the unit on at this time. Updates will only install while the unit is in charging mode.

5. POWER IT UP


After your KIT is completely charged and updated, it is ready to use.

- Press and hold the **Power** button for 2 seconds to power the unit ON.



6. SET IT UP

- Fully extend the rear leg of your KIT
- Place the unit 10 feet directly behind the ball
- Make sure the unit is level with the tee area and there are no obstructions



7. START A SESSION

- Open the Full Swing app and tap **Start Practice Session**
- Tap the **Connect** button, then tap **Join** when prompted
- Select your **Environment** and **Location** (optional), then tap **Start Session**
- Select a **Club**, then tap **Use Club & Set Target**
- Position your KIT so that the white line is pointed at your target, and your ball is within the tee area, then tap **Set Target Line**

HELP?

Help Center and FAQ: kitsupport.fullswinggolf.com

Phone: +1-855-688-1100

Email: kit.support@fullswinggolf.com

FULLSWINGGOLF.COM